



sportsattack.com
800.717.4251



SPEED
& SPIN
CONTROL



POWER	CIRCUIT BREAKER
ON	
OFF	
5-Second startup delay. Wait for beep.	

Ball Placement Instructions

Green/Basics Switch Positions:

- 1 - One line placement
- 2 - Two line placement
- 3 - Activates "White/Drills Switch" options

White/Drills Switch Positions: (Green/Basics Switch must be in position "3")

- R - Random
- 4 - Four ball drill - left, right, center, center
- 3 - Three ball drill - left, center, right

Width Dial: Controls distance between each ball placement. Position "10" is full court width.

Interval Dial: Controls 1 - 10 second feed frequency intervals. Position "10" is 10 seconds.

Feeder Switch: Push up to turn feeder on, push up again to turn off.

FEEDER

ON / OFF

LIFT

RAISE

LOWER

BALL PLACEMENT

INTERVAL	SWITCHES	WIDTH								
	<table border="1"> <tr> <th>DRILLS</th> <th>BASICS</th> </tr> <tr> <td>R</td> <td>1</td> </tr> <tr> <td>4</td> <td>2</td> </tr> <tr> <td>3</td> <td>3</td> </tr> </table>	DRILLS	BASICS	R	1	4	2	3	3	
DRILLS	BASICS									
R	1									
4	2									
3	3									